



Texas Electronics, Inc.

The Gold Standard in Weather Instrumentation Since 1957

Bird-B-Gone Strip

BB-525 24" Strip

Installation

Instructions for installing **Bird-B-Gone Strip** on Rain Gauge

1. Wrap the **Bird-B-Gone Strip** around the collector funnel of the rain gauge.
2. Attach the ends of the strip together with the enclosed cable ties.
3. You may also use a small amount of silicone adhesive to lock in place.
4. Bend the spikes upward for full coverage.

